

Simube Hub Firmware Upgrade Guide

1. Prepare the Device

Open the cover of the Shub device as shown in Figure 1. Move the switch located at the lower end of the PCB to the left position (PC mode) for firmware upgrade.

Important: After the upgrade is complete, you must switch it back to the right position (F mode); otherwise, the device will not function properly.



(Figure 1)

2. Launch the Update Application

Run the application S_Assistant provided by us on your computer, as shown in Figure 2.



(Figure 2)

3. Connect the Device

Use a USB data cable to connect the Shub device to your PC (we recommend using the USB cable supplied by Fanatec) as shown in Figure 3.

Once connected, the application will display the detected device as shown in Figure 4.



(Figure 3)



(Figure 4)

4. Update the Firmware

Click "Open File", select the latest firmware file we have provided, and then click "Update Firmware".

Wait until the progress bar reaches completion and you see the message "Flash Update Success", as illustrated in Figure 5.

You may now safely disconnect the USB cable.

Note: Do not perform any other operations during the update process to avoid upgrade failure.



(Figure 5)

⚠ IMPORTANT NOTICE: After completing the firmware upgrade, you must toggle the mode switch on the PCB to the right position (F mode); otherwise, the device will not operate properly.